


ADJUSTABLE LEVELING FEET

(🔩X4)



Four adjustable leveling feet for the modules. You can buy them from distributors if you want to install in this way.

Procedure:

1. Take the module out of the package.
2. Install four adjustable leveling feet.